



Rear Spring Spacer Set Fitting Instructions

Part Number:	TMG30720		
Description:	Spacer Set, Rear Spring, Lowering		
Applications:	MGB (Banjo Axle 1962-67)		
Kit Contents:	TMG3750	ALLOY SPACER BLOCK	2
	TMG3751	U BOLT, LONG, BANJO	4
	GHF223	NUT 3/8" UNF NYLOC	8

Notes

The fitting of the spacer set is very easy only requiring the car to be supported on axle stands with the wheels removed.

Now support the spring just forward of the axle unit and undo the standard nuts for the U bolts. Replace the U bolts with the new longer versions and refit. Make sure you check the condition of the existing rubber insulator and replace if required.

Fit the spacer into position, directly above the leaf spring, and reassemble by raising the leaf spring up to the axle height.

