



Rear Spring Spacer Set Fitting Instructions

Part Number:	TMG30721		
Description:	Spacer Set, Rear Spring, Lowering		
Applications:	MGB (Tube Axle 1968-80)		
Kit Contents:	TMG3750	ALLOY SPACER BLOCK	2
	TMG3751	U BOLT, LONG, TUBE AXLE	4
	GHF223	NUT 3/8" UNF NYLOC	8

Safety First

Working under or on a raised vehicle, ensure that it is safely supported with axles stands supported on the body. Performance parts put higher than normal loads on all other components. All components should be inspected for wear and for damage. They should be replaced if there is any doubt as to their condition. Moss Europe Ltd accepts no liability whatsoever for damage, loss or injury incurred as a result of using this literature.

Notes

The fitting of the spacer set is very easy only requiring the car to be supported on axle stands with the wheels removed.

Now support the spring just forward of the axle unit and undo the standard nuts for the U bolts. Replace the U bolts with the new longer versions and refit. Make sure you check the condition of the existing rubber insulator and replace if required.

Fit the spacer into position, directly above the leaf spring, and reassemble by raising the leaf spring up to the axle height.

